





00-1




13-19

- 14-1
- 14-2
- 14-3
- 14-4
- 14-5
- 14-4
- 14-7
- 14-8
- 14-9
- 14-10
- 14-11
- 14-12
- 14-13



13-2

- 10-1
- 10-2
- 11-3
- 11-1
- 11-2
- 11-4
- 11-5
- 11-6
- 13-1
- 13-4
- 13-8
- 13-9
- 13-10
- 13-6
- 13-5
- 13-7
- 13-11
- 13-13
- 13-14
- 13-15
- 13-14
- 13-17
- 13-18



- 08-3
- 08-2
- 08-1
- 00-2
- 09-1
- 09-2
- 09-3
- 09-3
- 00-4
- 00-5
- 00-3
- 03-1
- 04-1
- 04-2
- 01-1
- 05-1
- 05-2
- 01-2
- 01-5
- 01-4
- 01-4
- 01-3
- 19-1
- 01-3
- 19-3
- 19-2
- 19-3
- 19-1
- 19-2
- 15-1
- 15-2
- 16-1
- 17-1
- 17-2
- 17-3
- 17-2
- 17-4
- 17-4
- 00-6
- 18-1
- 18-2
- 18-3
- 18-4
- 18-5
- 18-6
- 18-7



00-7



07-2

07-1

- 01-4
- 01-4
- 01-3
- 19-1
- 01-3
- 19-3
- 19-2

From 11/02/2015

	Part Number	Part Name	Qty
		Spare Parts	
00-1	KITSTICKIDYLLE13	Sticker Kit IDYLLE 2011	1
00-2	ADHSP01-08	Frame Bumbstop	2
00-3	JT300004B5	O-ring	1
00-4	150707-D-060	Right Stanchion	1
00-5	150707-D-061	Left Stanchion	1
	150707D1562	Long Spring 0,60 (<60kg)	1
00-6	150707D1564	Long Spring 0,68 (60 à 80 kg)	1
	150707D1566	Long Spring 0,76 (80 à110 kg)	1
00-7	HU03B	Bio oil	1
01-4	150707-D-151	Screw Support	1
18-5	CTB33B	Retaining Ring	1
	150707SE001/W	White Lowers Kit 26'	
01-1	JT300010A3	O'ring	2
01-2	150707-D-1501G	White Lowers	1
01-3	VVCHC0516A0	Socket Head Screw	4
01-4	150707-D-151	Screw Support	2
01-5	150707-D-016A	Lowers Insert	2
03-1	RXWT000083	Scraper Seal	2
04-1	150707-D-148A	Upper Bushing	2
04-2	150707-D-149A	Lower Bushing	2
05-1	150707-D-094A	Hose guide	1
05-2	VVCHC0306A0	Socket Head Screw	2
	150707SE001/B	Black Lowers Kit 26'	
01-1	JT300010A3	O'ring	2
01-2	150707-D-1502G	Black Lowers	1
01-3	VVCHC0516A0	Socket Head Screw	4
01-4	150707-D-151	Screw Support	2
01-5	150707-D-016A	Lowers Insert	2
03-1	RXWT000083	Scraper Seal	2
04-1	150707-D-148A	Upper Bushing	2
04-2	150707-D-149A	Lower Bushing	2
05-1	150707-D-094A	Hose guide	1
05-2	VVCHC0306A0	Socket Head Screw	2
	150707-SE-003	Scraper Seals Service Kit	
03-1	RXWT000083	Scraper Seal	2
00-3	JT300004B5	O'ring	1
	150707-SE-004	Bushing Service Kit	
04-1	150707-D-148A	Upper Bushing	2
04-2	150707-D-149A	Lower Bushing	2
	150707-SE-007	Axle	
07-1	150707-D-007D	Wheel Axle	1
07-2	150707-D-009	Axle Cap	1
	150707-SE-008	Upper Crown Kit 26'	
08-1	150707-D-055B2	Upper Crown 26'	1
08-2	VVCHC0516A0	Socket Head Screw	2
08-3	VVCHC0620A0	Socket Head screw	1
	150707-SE-009	Lower Crown Kit 26'	
09-1	150707-D-008D	Steerer tube	1
09-2	150707-D-056-A2	Lower Crown 26'	1
09-3	VVCHC0516A0	Socket Head Screw	4
	150707-SE-010	Bleed Bolt	
10-1	VVCHC0306A0	Socket Head screw	1
10-2	JT030019A3	O'ring	1
	150707-SE-011A	Rebound Cap Kit	
10-1	JT030019A3	O'ring	1
10-2	VVCHC0306A0	Socket Head screw	1
11-1	150707-D-027B	Rebound Cap	1

11-2	JT280004A3	O'ring	1
11-3	B25A	Indexation Ball	1
11-4	JT080007B5	O'ring	1
11-5	JT044703A3	O'ring	1
11-6	150707-D-021B	Rebound Screw	1
	150707-SE-013	Rebound Kit	
13-2	150707-D-076	Transmission	1
13-4	150707-D-075B	Rod	1
13-5	GT01A10A	DU Bushing	1
13-6	151108-D-012	Shaft Guide	1
13-7	150707-D-154	Spring	1
13-8	151108-D-082	Needle	1
13-9	JT040002A3	O'ring	1
13-10	RA1256670A	Rebound Spring	1
13-11	150707-D-022B	Rebound Piston Support	1
13-13	151613-D-039	Shim Spring	1
13-14		Shims	
13-15	150707-D-041	Piston Guide	1
13-16	150707-D-028B	Rebound Piston	1
13-17	230104-D-040B	Top Plate	1
13-18	VEN06B0	Nylstop Nut	1
	150707-SE-014	Compression Kit	
14-1	VEN06B0	Nylstop Nut	1
14-2	150707-D-023A	Shim Guide	1
14-3	151613-D-039	Shim Spring	1
14-4		Shims	
14-5	JT150002A3	O'ring	1
14-6	150907-D-008A	Compression Piston	1
14-7	230104-D-040B	Top Plate	1
14-8	JT080007A3	O'ring	1
14-9	B25A	Indexation Ball	2
14-10	150707-D-072A	Compression Block	1
14-11	JT200004A3	O'ring	1
14-12	JT050002A3	O'ring	1
14-13	150707-D-071	Compression Needle	1
	150707-SE-015	Preload Cap Kit	
15-1	150707-D-144A	Fixed Preload Cap	1
15-2	JT280004A3	O'ring	1
	150707-SE-016	Spring Side Preload Kit	
16-1	150707-D-147	Preloading Washer 3mm	3
	150707-SE-017	Spring Side Anti Volume Kit	
17-1	150707-D-095A	Preloading Spring Support	1
17-2	JT230004A3	O'ring	2
17-3	150707-D-172	Cylinder	1
17-4	150707-D-096B	Spring Support	1
	150707-SE-018	Spring Shaft	
18-1	150707-D-036D	Piston	1
18-2	150707-D-042B	Piston Guide	1
18-3	150707-D-154	Spring	2
18-4	150707-D-037C	Spring Guide	1
18-5	CTB33B	Retaining Ring	1
18-6	150707-D-040D	Spring Rod Guide	1
18-7	150707-D-038A	Spring Rod Support	1
19-1	JT220004A3	O'ring	2
19-2	150707-D-039B	Left Lower Side Nut	1
	150707-SE-021	High Rise Upper Crown Kit	
08-2	VVCHC0516E0	Titanium Screw	2
08-3	VVCHC0616A0	Socket Head screw	1
08-4	150707-D-182	High Rise Upper Crown	1
	150707-SE-028A	Complete Hydraulic Side	
10-1	JT030019A3	O'ring	1
10-2	VVCHC0306A0	Socket Head screw	1
11-1	150707-D-027B	Rebound Cap	1

11-2	JT280004A3	O'ring	1
11-3	B25A	Indexation Ball	1
11-4	JT080007B5	O'ring	1
11-5	JT044703A3	O'ring	1
11-6	150707-D-021B	Rebound Screw	1
13-1	150304-D-006D	Rod Nut	1
13-2	150707-D-076	Transmission	1
13-4	150707-D-075B	Rod	1
13-5	GT01A10A	DU Bushing	1
13-6	151108-D-012	Shaft Guide	1
13-7	150707-D-154	Spring	1
13-8	151108-D-082	Needle	1
13-9	JT040002A3	O'ring	1
13-10	RA1256670A	Rebound Spring	1
13-11	150707-D-022B	Rebound Piston Support	1
13-13	151613-D-039	Shim Spring	1
13-14		Shims	
13-15	150707-D-041	Piston Guide	1
13-16	150707-D-028B	Rebound Piston	1
13-17	230104-D-040B	Top Plate	1
13-18	VEN06B0	Nylstop Nut	1
13-19	150707-D-067A	Cartridge Support	1
14-1	VEN06B0	Nylstop Nut	1
14-2	150707-D-023A	Shim Guide	1
14-3	151613-D-039	Shim Spring	1
14-4		Shims	
14-5	JT150002A3	O'ring	1
14-6	150907-D-008A	Compression Piston	1
14-7	230104-D-040B	Top Plate	1
14-8	JT080007A3	O'ring	1
14-9	B25A	Indexation Ball	2
14-10	150707-D-072A	Compression Block	1
14-11	JT200004A3	O'ring	1
14-12	JT050002A3	O'ring	1
14-13	150707-D-071	Compression Needle	1
19-1	JT220004A3	O'ring	1
19-3	150707-D-073	Right Lower Side Nut	1
	150707-SE-030	Bolts Kit	
01-4	150707-D-151	Axle Screw Support	2
01-5	150707-D-016A	Lowerleg Insert	2
08-2	VVCHC0516A0	Socket Head screw	10
08-3	VVCHC0620A0	Socket Head screw	1
	150707-SE-051	Right Lower Cartridge Nut	
19-1	JT220004A3	O'ring	1
19-3	150707-D-073	Right Lower Side Nut	1
	150707-SE-052A	O'ring Kit	
00-3	JT300004B5	O'ring	1
01-1	JT300010A3	O'ring	2
10-2	JT030019A3	O'ring	1
11-2	JT280004A3	O'ring	1
11-4	JT080007B5	O'ring	1
11-5	JT044703A3	O'ring	1
13-9	JT040002A3	O'ring	1
14-5	JT150002A3	O'ring	1
14-8	JT080007A3	O'ring	1
14-11	JT200004A3	O'ring	1
14-12	JT050002A3	O'ring	1
15-2	JT280004A3	O'ring	1
17-2	JT230004A3	O'ring	2
19-1	JT220004A3	O'ring	2
	150707-SE-053	Left Lower Cartridge Nut	
19-1	JT220004A3	O'ring	1
19-2	150707-D-039B	Left Lower Side Nut	1

	150707SE071/W	White Lowers Kit 27,5'	
01-1	JT300010A3	O'ring	2
01-2	150707D1501H	White Lowers	1
01-3	VVCHC0516A0	Socket Head Screw	4
01-4	150707-D-151	Screw Support	2
01-5	150707-D-016A	Lowers Insert	2
03-1	RXWT000083	Scraper Seal	2
04-1	150707-D-148A	Upper Bushing	2
04-2	150707-D-149A	Lower Bushing	2
05-1	150707-D-094A	Hose guide	1
05-2	VVCHC0306A0	Socket Head Screw	2
	150707SE071/B	Black Lowers Kit 27,5'	
01-1	JT300010A3	O'ring	2
01-2	150707D1502H	Black Lowers 27,5	1
01-3	VVCHC0516A0	Socket Head Screw	4
01-4	150707-D-151	Screw Support	2
01-5	150707-D-016A	Lowers Insert	2
03-1	RXWT000083	Scraper Seal	2
04-1	150707-D-148A	Upper Bushing	2
04-2	150707-D-149A	Lower Bushing	2
05-1	150707-D-094A	Hose guide	1
05-2	VVCHC0306A0	Socket Head Screw	2
	150707-SE-072	Upper Crown Kit 27,5'	
08-1	150707-D-186A	Upper Crown 27,5'	1
08-2	VVCHC0516A0	Socket Head Screw	2
08-3	VVCHC0616A0	Socket Head screw	1
	150707-SE-073	Lower Crown Kit 27,5'	
09-1	150707-D-008D	Steerer tube	1
09-2	150707-D-185A	Lower Crown 27,5'	1
09-3	VVCHC0516A0	Socket Head Screw	4
	150707-SE-075	One Side Axle Fitting	
01-3	VVCHC0516A0	Socket Head Screw	2
01-4	150707-D-151	Screw Support	1
01-5	150707-D-016A	Lowers Insert	1
	151108-SE-005	Hose Guide Unit	
05-1	150707-D-094A	Hose guide	1
05-2	VVCHC0306A0	Socket Head screw	2