



	Part Number	Part Name	Qty
Spare Parts			
0-2	JT300002A3	O'ring	1
	151008D013/3	Cylinder 222	1
0-3	151008D013/4	Cylinder 240	1
	151008D013/5	Cylinder 267	1
0-4	JT290002A3	O'ring	1
0-5	151008-D-035B	Piggy bag (222 / 240)	1
	151008-D-039	Piggy bag (267)	1
0-6	150807-D-029A	Bumb Stop Cylinder (STOY2 RARE 240-267)	1
	150807-D-058	Bumb Stop Cylinder (STOY2 RARE 222)	1
4-1	151512-D-013A	HS Valve	1
4-2	151512D010/2A	HS Spring	1
7-3	150406-D-008A	Top Plate	1
	SETST01	Setting VOID ST01	1
	SETST02	Setting VOID ST02	1
	SETST03	Setting VOID ST03	1
7-4	SETST04	Setting VOID ST04	1
	SETST05	Setting VOID ST05	1
	SETST06	Setting VOID ST06	1
	SETST10	Setting VOID ST10	1
7-8	150005-D-012B	Top Plate	1
7-9	150807-D-059	Bumb Stop Piston (VOID RARE 222)	1
	150807-D-039A	Bumb Stop Piston (VOID RARE 240/267)	1
7-13	VEHM08A1	Nut	1
9-1	151008-D-019A	Shaft Eyelet 15*12,7	1
12-6	JT300005A3	Negative Anti-volume O'ring	2
14-1	JT473503A3	O'ring	1
	151008D036/3	Air Chamber 222	1
14-2	151008D036/4	Air Chamber 240	1
	151008D036/5	Air Chamber 267	1
15-4	319300	Valve Core	1
16	HU01B	AMX1 Oil	1
	151008S001/222	Sticker Kit VOID2 222 Yellow	1
17	151008S001/240	Sticker Kit VOID2 240 Yellow	1
	151008S001/267	Sticker Kit VOID2 267 Yellow	1
	151008-S-003/YT15	Sticker Kit VOID2 267 Red YT	1
Black Piggy Back Cap			
6-1	VVCHC0406A0	Socket Head Screw	1
6-6	150807-D-008	Retaining Ring	1
6-2	JT030002A3	O'ring	1
6-3	JT218906A3	O'ring	1
6-4	150807D0072D	Gas Canister Cap	1
6-5	130402052	Gas Canister Valve	1
Axle mount 49x8			
10-1	150807-D-053	Axle 49x8	1
10-2	150807-D-054	Spacer 49x8	2
10-3	GT01A12C	DU BUshing	1
10-4	JT090002A3	O'ring	2
Low Speed Knob Kit			
3-5	151512-D-002	Retaining Ring	1
3-4	151008-D-033	LS Adjuster	1
3-2	RA4025045B	Indexation Spring	1
3-3	B25A	Indexation Ball	2
3-1	JT070002A3	O'ring	1
High Speed Knob Kit			
4-7	151512-D-002	Retaining Ring	1
4-6	151008-D-034	HS Adjuster	1
4-5	B25A	Indexation Ball	2
4-4	RA4025045B	Indexation Spring	1
4-3	JT070002A3	O'ring	1
Rebound Knob			

11-1	150807-D-033	Rebound Adjuster	1
11-2	RA4025045B	Indexation Spring	1
11-3	B25A	Indexation Ball	2
11-4	JT070002A3	O'ring	1
150807-SE-030 Bearing Complete Rebuild kit			
10-5	150807-D-017D	MK Axle	1
10-6	F1010	Needle Bearing	1
10-7	JT100021A3	O'ring	2
150807-SE-031 Bearing Light Rebuild kit			
10-5	150807-D-017D	MK Axle	1
10-7	JT100021A3	O'ring	2
150807-SE-032 Standard Rebuild kit			
10-8	JT090002A3	O'ring	2
10-3	GT01A12C	DU Bushing	1
150807-SE-033 Demo Rebound Knob			
11-1	150807-D-057A	Rebound Adjuster	1
11-2	RA4025045B	Indexation Spring	1
11-3	B25A	Indexation Ball	2
11-4	JT070002A3	O'ring	1
151008-SE-003 Shaft Guide Unit			
8-1	BAE44039810E	PTFE Ring	2
8-2	JT380005A3	O'ring	1
8-3	BAE16212010E	Split Ring	1
8-4	JT123706A3	O'ring	1
8-5	151008-D-014A	Shaft Guide	1
8-6	JT250002A3	O'ring	1
8-7	GT01A12A	Bushing	1
8-8	150807-D-005B	Rebound BumbStop	1
151008-SE-007A Valve Unit			
15-5	JT060002A3	O'ring	1
15-6	151310-D-022	Valve Cap	1
15-1	151008-D-008A	Rotary Valve Support	1
15-2	JT060001A3	O'ring	1
15-3	151310-D-006B	Valve support	1
15-4	319300	Valve Core	1
151008SE008/3 Air Sleeve Unit 222			
13-1	JT460004A3	O'ring	2
13-3	151008-D-016	Retaining Ring	1
13-2	151008D011/3B	Air Sleeve 222	1
151008SE008/4 Air Sleeve Unit 240			
13-1	JT460004A3	O'ring	2
13-3	151008-D-016	Retaining Ring	1
13-2	151008D011/4B	Air Sleeve 240	1
151008SE008/5 Air Sleeve Unit 267			
13-1	JT460004A3	O'ring	2
13-3	151008-D-016	Retaining Ring	1
13-2	151008D011/5B	Air Sleeve 267	1
151008-SE-009 Progressivity Setup Kit			
14-3	JT500005A3	O'ring	10
151008-SE-013A Eyelet Cap Kit			
9-11	151008-D-012B	Eyelet Cap	1
9-10	JT378203A3	O'ring	1
9-12	JT120002A3	O'ring	1
151310-SE-002 Valve Cap Kit			
15-5	JT060002A3	O'ring	1
15-6	151310-D-022	Valve Cap	1
151008-SE-017 Bumbstop			
9-8	JT100007A3	O'ring	1
9-9	CLAPD1224030	Shim	1
151008-SE-018 Piston unit			
7-7	150807-D-031	Piston	1
7-6	JT230001A3	O'ring	1
7-5	150807-D-016	Piston Guide	1

150807-SE-025B		Floating Piston	
5-2	150807-D-016	Piston guide	2
5-1	151008-D-038A	Gas Separator	1
5-3	JT218906A3	O'ring	1
151008-SE-019		Negative Air Chamber Unit	
12-2	151008-D-040	Negative Air Chamber	1
12-4	JT298206A3	O'ring	1
12-3	BAE34530010E	PTFE Ring	1
12-1	JR03B300D	Scraper Seal	1
12-5	151008-D-041	PTFE Guide	1
151008-SE-020		Light Rebuilt Kit	
0-7	JT260002B5	O'ring	1
9-8	JT100007A3	O'ring	1
8-2	JT380005A3	O'ring	1
8-4	JT123706A3	O'ring	1
8-6	JT250002A3	O'ring	1
8-7	GT01A12A	Bushing	1
12-4	JT298206A3	O'ring	1
12-1	JR03B300D	Scraper Seal	1
151008-SE-021		Complete Rebuilt Kit	
0-7	JT260002B5	O'ring	1
12-4	JT298206A3	O'ring	1
12-1	JR03B300D	Scraper Seal	1
9-8	JT100007A3	O'ring	1
8-1	BAE44039810E	PTFE Ring	2
8-2	JT380005A3	O'ring	1
8-3	BAE16212010E	Split Ring	1
8-4	JT123706A3	O'ring	1
8-5	151008-D-014A	Shaft Guide	1
8-6	JT250002A3	O'ring	1
8-7	GT01A12A	Bushing	1
8-8	150807-D-005B	Rebound BumbStop	1
151008-SE-023		Head Eyelet Kit	
0-1	151008-D-032B	Head	1
0-2	JT300002A3	O'ring	1
0-4	JT290002A3	O'ring	1
1-1	151008-D-037B	Barrel cap	1
1-2	JT080001A3	O'ring	1
1-3	JT060002A3	O'ring	1
1-4	VVSTHC0304A0	Screw	1
1-5	CTA11A	Circlip	1
1-6	VVSTHC0306A0	Screw	1
1-7	151008-D-046	Cap	1
2-1	151008-D-045A	Head cap	1
2-2	JT045002A3	O'ring	1
2-3	151008-D-044	Spring	1
2-4	CLAPD0608030	Shims	2
2-4	CLAPD0612020	Shims	1
2-5	JT160002A3	O'ring	1
2-6	151008-D-043A	Check Valve Seat	1
2-7	VVCHC0406A0	Screw	1
151008-SE-024		Head cap kit	
1-6	VVSTHC0306A0	Srew	1
1-7	151008-D-046	Cap	1
151008-SE-025		Shaft Kit 222	
7-1	JT065002A3	O'ring	1
7-2	150807-D-030A	Rod End	1
9-4	TV03/96A	Shaft 222	1
9-5	JT020002A3	O'ring	1
9-6	PV01-101.5E	Needle 222	1
151008-SE-026		Shaft Kit 240	
7-1	JT065002A3	O'ring	1
7-2	150807-D-030A	Rod End	1

9-4	TV03/103A	Shaft 240	1
9-5	JT020002A3	O'ring	1
9-6	PV01-108.5E	Needle 240	1
151008-SE-027		Shaft Kit 267	
7-1	JT065002A3	O'ring	1
7-2	150807-D-030A	Rod End	1
9-4	TV03/117.5A	Shaft 267	1
9-5	JT020002A3	O'ring	1
9-6	PV01-123.0E	Needle 267	1